



208700-041315-00000



FILTER ASSEMBLY
INSIDE-OUT ELEMENT FLOW

FIG. I


10081315 - 044802



FILTER ASSEMBLY
OUTSIDE-IN ELEMENT FLOW

FIG. 2

10081315 - 041802



10081315 - 041802






FIG. 4

10081315 - 0441802




PRE FILTER & AFTER FILTER
INSIDE-OUT UPSTREAM ELEMENT FLOW
INSIDE-OUT DOWNSTREAM ELEMENT FLOW

FIG. 5




PRE FILTER & AFTER FILTER
INSIDE-OUT UPSTREAM ELEMENT FLOW
OUTSIDE-IN DOWNSTREAM ELEMENT FLOW

FIG. 6




PRE FILTER & AFTER FILTER
INSIDE-OUT UPSTREAM ELEMENT FLOW
INSIDE-OUT DOWNSTREAM ELEMENT FLOW

FIG. 7



INSIDE-OUT ELEMENT FLOW MOUNTING PLATE


FIG. 6A



OUTSIDE-IN ELEMENT FLOW MOUNTING PLATE

FIG. 6B

10081315.0441802




INSIDE-OUT ELEMENT FLOW PREFILTER MOUNTING PLATE

FIG. 8C


10081315.041802

208T-00-STET802



OUTSIDE-IN ELEMENT FLOW ADAPTER

FIG. 9A




INSIDE-OUT ELEMENT FLOW PREFILTER ADAPTER

FIG. 98

10081315.041802


10081315 - 041802



OUTSIDE-IN ELEMENT FLOW AFTER FILTER ADAPTER

FIG. 9C

10081315 - 0441862



INSIDE-OUT ELEMENT FLOW AFTER FILTER ADAPTER


FIG. 90



CONDUIT SEAL RETAINER
FIG. 10




INLET FLOW EXTENSION CONDUIT
FIG. 11A




INLET FLOW EXTENSION CONDUIT
FIG. 11B

10081315 - 0441802



FILTER ELEMENT
INSIDE-OUT FLOW
(PRIOR ART)

FIG. 12



FILTER ELEMENT
OUTSIDE-IN FLOW
(PRIOR ART)

FIG. 13

10081315-041802